

# Developments of RIB Target Module and Remote Handling System at RI SP

J.H. Lee, H. Ishiyama, C.S. Seo, B.H. Kang, S.J. Pyun, S.J. Park,  
M.J. Kim, J.C. Kim, S. Choi, Y.H. Kim, Y.G. Choi, S.C. Jeong

RI Experimental Systems Team, RISP, IBS, Korea




# Requirements for ISOL RH System



- 70 kW beam power to the UCx Target (10 kW in RISP)
- Two-stage target station and pre-mass separator
- TIS (Target/Ion Source) and beam line components shall be modular for remote maintenance
- Target and target module service by remote handling (exchange, repairs, maintenance and re-installation) in radioactive area
- Remote device – Lock & Lifting fixtures / Special Couplings, Manipulator tools
- Execution of mock-up test before beam commissioning at on-line site
- Application of Radiation hardness material
- Benchmarking the TRIUNF building and Remote Handling system


# Target Station & Maintenance Hall





**63 m(W) x 11.5 m(L) x 18 m(H)**

# Residual Radiation Analysis for Service Zone of Target Station


- 70 MeV / 1mA Proton beam with UC<sub>2</sub> Target
- Activation: 14 Day Irradiation with 14 Day Decay, Repeated for 30 year
- Gap between the concrete block : 1 cm
- MCNPX and SP-FISPACT-2010 Code




Shielding Blocks (Movable)





< Prompt Neutron Dose Distribution of Target Station Area >




< 0 s >



< 1 d >



< 7 d >




< 30 d >

< Residual Dose Distribution >

< Maximum Dose in Service Zone of Target Station >


Decay Time	0 Sec.	1 Hour	1 Day
Dose [uSv/hr]	9.256E+02	7.146E+02	1.156E+02
Relative Error	0.031346	0.028189	0.012426
Decay Time	7 Days	30 Days	1 Year
Dose [uSv/hr]	1.952E+01	1.671E+01	7.846E+00
Relative Error	0.097676	0.101224	0.025335

# ISOL Target Operation Cycle




# ISOL Target Module


- Vacuum Chamber & Target Module
- Primary Vacuum zone : Target chamber & Beam line
- Secondary vacuum zone : Module external volumes
- Three Special All metal gate valves
- Three Pillow Seals : Inter module connection
- High Voltage Tray
  - Insulation : BN Powder or Arocy L-10 cyanate ester resin
  - Feedthroughs & Quick/Remote connectors
- Shielding Materials : Heavy Concrete Block




< Target Module, 1.4 m(W) x 1.5 m(L) x 3.3 m(H) >



< Remote Multi Connection Panel (Designed by STAUBLI) >




< Pillow Seal (technical assistance by KEK) >




< Extended All Metal Gate Valve >


# Target Module & Target Station Overview




< Vacuum Chamber and TM >




< Target Module >




< Target Station Concept >




< Front-end System component >



10 kW Faraday Cup  
Ø45 mm Collimator  
< Proton Beam Diagnostic Module >



< RI Beam EQT Module >




< RI Beam Diagnostic Module >

# ISOL Target Hall Remote Crane

## Main remote crane use for :

- Target Module & shield block removal / replacement
- Target chamber transfer
- Waste target handing
- maintenance



ITEM	SPECIFICATION	REMARK
Lifting capacity	20T / 3T / 3T	
Actual Lift	18/17.2/17.2 m	
Operation Mode	Normal / Emergency	
Lifting speed	1mm/s to 100mm/s	
Control dirve	x-y-z	
Rotation	360°	
Rotation speed	1.2 rpm	
Position accuracy	2mm	Rack Gear
Lifting indicator	20 kg precision	
Emergency capacity	DC motor (with battery)	

## Safety & Control :


- Auto/ manual/ Semi-Auto (with vision system)
- Snag detection / Auto Centering (Vision system)
- Reverse rotation prevention (hydraulic disc brake)
- Auto switching to DC Motor when motor failure occurs
- Operation Speed variable
- Dual position encoders
- All control devices located outside Target hall





# Crane Interface Device

- Remote interface of Target Module & Shield Blocks
- Modularize for all components and prevent from radiation exposure
- Interlock & Safety

- 1) Alignment check after transfer to Target Module & Shield Block
- 2) Move to alignment point
- 3) Move down & combine alignment pin with hole
- 4) Displacement & interlock sensing
- 5) Lock on




Displacement



\* Twist rock system used at J-PARC Hadron Facility


# Target Module Remote Removal Concept

## Remote Crane




Hot Cell TM Storage Pre-separator Room Target Station Pre-separator Room


- 1) Remove shielding blocks of service zone
- 2) All metal gate valve close
- 3) Decouple Pillow seals
- 4) Break secondary and primary vacuum by Ar gas
- 5) Purge cooling waters from duct
- 6) Quick/remote disconnect all electric cables, water cooling / gas lines
- 7) Connect target module to remote crane and unload target module in vacuum chamber
- 8) Move to hot cell
- 9) Put the target module in hot cell and decouple the crane
- 10) Insert a shielding plug into vacuum chamber




SB : Shield Block  
 TC : Target Chamber  
 TM : Target Module  
 VC : Vacuum Chamber  
 RC : Remote Connector  
 ROM : RIB Optics Module  
 BDM : Beam Diagnostic Module  
 SP : Shielding Plug  
 ■ : Pillow Seal  
 ■ : Gate Valve




# Target Exchange in Hot Cell




# Spent Target Storage



< ISAC/TRIUMF Target Storage Vault >




< ARIEL/TRIUMF Target Storage Vault >



< Target Chamber Stocker system >

# Target Module & Hot Cell Mock-up



< 4,800mm(W) x 6,852 mm(L) x 4,500 mm(H) >

## Target Module Performance Test


- Primary & Secondary Vacuum Test
- Quick & Remote Connection/Disconnection
- High Voltage Discharge
- Pillow Seal & Special All Metal Gate Valve

## Hot Cell Performance Test

- Coupling & Decoupling of Target Chamber in Target Module
- Target Chamber Exchange
- Target Module Moving System (Rot. & Up/Down)
- Manipulator Jig & Tools

## Crane Interface Device Performance Test

- Alignment / Twist Locking / Interlock



# Summary

- RISP ISOL systems are being developed for providing n-rich RI beam to user facility
- Detail and Engineering Design of ISOL remote handling system including infrastructure under way
- Final Goal : 70 kW UCx Target Ion Source system (in RISP 10 kW)
- Start install in 2019, 2021 RI beam providing
- Benchmarked the TRIUMF target module and remote handling system
- Target remote handling scenario defined
- All remote procedures to be mocked-up and tested prior to commissioning with beam.
- Target module and hot cell mock-up in progress of manufacture





**Thank you for your attention !**